



FLEXAMAT INFORMATION

Manufacturer: Motz Enterprises, Inc.
 Product Name: Flexamat®
 Address: 3153 Madison Road
 Cincinnati, Ohio 45209
 Telephone: 513-772-MOTZ (6689)
 Fax: 513-772-6690
 Contact: Matt Motz
 Email: Matt@Flexamat.com
 Website: www.Flexamat.com

CONSTRUCTION NOTES:

- GRADE CHANNEL SO THAT WATER WILL FLOW DOWN THE CENTER OF THE CHANNEL AND BE CONTAINED TO THE CHANNEL. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND. THE PREPARED SURFACE SHALL PROVIDE A FIRM UNYIELDING FOUNDATION FOR THE MATS.
- APPLY SEED DIRECTLY TO THE PREPARED SOIL PRIOR TO FLEXAMAT INSTALLATION. USE SEED PER PROJECT SPECIFICATIONS.
- INSTALL FLEXAMAT ROLLS. AVAILABLE WIDTHS ARE 4', 5.5', 8', 10', 12', & 16'.
 - TO ACHIEVE WIDER WIDTHS, INSTALL MATS ADJACENT TO ONE ANOTHER. BRIDGE LONGITUDINAL SEAM WITH 48" UNDERLAYMENT SEAM. 24" OF UNDERLAYMENT SHALL BE UNDER EACH MAT AND DIRECTLY AGAINST THE SUBGRADE.
 - FLIP FLEXAMAT SECTIONS BACK INTO PLACE SO THAT THEY FIT TIGHTLY.
 - INSTALL 18" U-ANCHORS IN 3' INCREMENTS THE LENGTH OF THE LONGITUDINAL SEAM. U-ANCHORS CONSIST OF #3 REBAR SHAPED INTO A U SHAPE WITH 18" LEGS.
- AT THE BEGINNING OF CHANNEL, THE INITIAL LEADING EDGE OF FLEXAMAT EXPOSED TO CONCENTRATED FLOWS SHALL BE EMBEDDED 18" VERTICALLY INTO THE SUB GRADE TO SERVE AS AN ANCHOR TRENCH. THE TRENCH SHALL BE FILLED AND COMPACTED WITH SUITABLE FILL OR OTHER (AS SPECIFIED BY EOR).
- INSTALL 18" U-ANCHORS IN 2' INCREMENTS BEHIND THE FIRST ROW OF BLOCKS EXTENDING FROM ANCHOR TRENCH. INSTALL ANCHORS DIRECTLY BEHIND BLOCKS.
- FOR ADDITIONAL SECTIONS OF MAT, OVERLAP THE DOWNSTREAM SECTION 18" WITH UPSTREAM SECTION OF MAT. PRIOR TO INSTALLING OVERLAP, FLIP UPSTREAM MAT BACK 24". EXCAVATE 2.25" OF SOIL 18" FROM END OF UPSTREAM MAT. DOWNSTREAM SECTION IS LAID IN THE SHALLOW TRENCH. LIGHTLY SPREAD TOPSOIL OVER INITIAL EDGE. FLIP END OF UPSTREAM MAT OVER THE SOIL COVERED INITIAL LEADING EDGE OF DOWNSTREAM MAT.
- INSTALL 18" "U" ANCHORS IN 2' INCREMENTS ACROSS THE OVERLAP. INSTALL ANCHORS DIRECTLY BEHIND BLOCKS.
- OUTSIDE EDGES OF THE MAT EXPOSED TO SURFACE FLOW SHALL HAVE THE OUTSIDE BLOCK RECESSED 6" IN SUBGRADE.



Distributed by:

www.aspent.com

1-800-869-9600

www.quicksupplydm.com

1-800-362-2245