



Distributed by:  
 www.aspent.com 1-800-869-9600  
 www.quicksupplydm.com 1-800-362-2245



# Flexamat Project Check List:

Here are some suggestions for a successful Flexamat installation:

- Decide which Flexamat option is best for the site.
    - 1. Curlex II
    - 2. Curlex II & Recyclex Combo (Flexamat PLUS)
    - 3. Geotextile (10 oz.)
  - Order Flexamat (may need up to 5-7% waste factor)
  - Have installation crew watch videos on Flexamat’s YouTube Channel
  - Plan staging area for Flexamat (helps reduce trucking issues and allows for advance ordering)
  - Prepare work prior to installation – remove stumps, rocks, soil, etc – for smooth surface
  - Seed and fertilizer, this needs to be done prior to installation of Flexamat
  - Clevis shackle of appropriate weight rating. (For connecting to D-ring on bucket.)
  - Swivel and rigging with latched sling hooks of appropriate weight rating.
  - 3-4 hay bale hooks (Used for adjusting Flexamat as needed during installation.)
  - Lifting straps for large rolls.
  - Smooth (toothless) bucket on excavator (refer to install videos)
  - May be needed - #3 rebar 18” U-Anchors
  - May be needed - 4’ Curlex II for seams and edges
  - May be needed - Geogrid for splices
  - May be needed - Zip ties (same ones used for silt fence) or hog rings and hog ring pliers
- 
- Gloves
  - Rakes & Shovels
  - Hay hooks
  - Clevis
  - Swivel and rigging w/ latched sling hooks
  - Chop saw if cutting is required



Swivel Attachment Rigging



Sling Hook with Latch



Hay Hooks