



FLEXAMAT[®] INFORMATION

Manufacturer: Motz Enterprises, Inc.
Product Name: Flexamat
Address: 3153 Madison Road
 Cincinnati, Ohio 45209
Telephone: 513-772-6689
Fax: 513-772-6690
Contact: Matt Motz
 Matt@Flexamat.com
Website: www.Flexamat.com

CONSTRUCTION NOTES:

1. GRADE A UNIFORM SUBGRADE. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF STICKS, ROOTS, OR DEBRIS OF ANY KIND. THE PREPARED SURFACE SHALL PROVIDE A FIRM UNYIELDING FOUNDATION FOR THE MATS.
2. PRIOR TO INSTALLING THE FLEXAMAT, SEED THE SLOPE WITH SITE SPECIFIC SEED.
3. INSTALL FLEXAMAT ROLLS. THE TOP OF THE MAT SHALL EXTEND 2' PAST THE CREST OF SLOPE. TOP EDGE OF MAT SHALL BE ANCHORED 18" VERTICALLY IN ANCHOR TRENCH. AT THE TOE OF THE SLOPE, TRENCH THE MAT 18".
4. ABUT EACH SECTION OF MAT TIGHTLY TO THE PREVIOUS SECTION. INSTALL A 4' SECTION OF CURLEX II ECB UNDER THE ABUTTED FLEXAMAT PANELS, BRIDGING THE SEAM EQUALLY SO THAT 24" OF THE ECB IS UNDER EITHER MAT.



ASP Enterprises-STL
 1099 Cassens Ind. Ct.
 Fenton, MO 63026
 TF: 800-869-9600
www.aspent.com

ASP Enterprises-KC
 5301 E. 59th St.
 Kansas City, MO 64130
 TF: 800-519-2304
www.aspent.com

ASP Enterprises-Omaha
 15263 Cooper St.
 Omaha, NE 68138
 TF: 877-678-8027
www.aspent.com

FLEXAMAT[®]
SLOPE ARMORING DETAIL

